

SMC30B / SMC30C

Step Motor Controller

User's Manual




JVL Industri Elektronik A/S - March 1991

Contents

1.1	Introduction	3
1.2	Controller Connections	4
Driver Section		
2.0	Block Diagram	6
2.1	Power Supply	7
2.2	Motor Connection	9
2.3	User Outputs	12
2.4	Clock Output	13
2.4	User Inputs	14
2.5	Analogue Inputs	16
2.6	CW and CCW End-of-Travel Inputs	17
2.7	Stop Input	18
2.8	Pin Designations	19
Controller Section		
3.1	Interface Connections	20
3.2	Addressing	21
3.3	Communication Rate	22
3.4	Command Syntax	23
3.5	Checksum	24
3.6	Module Interface	25
Software Description		
4.1	General	27
4.2	Command Overview	30
4.3	System Commands	33
4.4	Motor Commands	36
4.5	User Interface	46
4.6	Flow Commands	49
Appendices		
5.1	Electrical Data	65
5.2	Physical Dimensions	67
5.3	Memory Allocation	68
5.4	Connector Board for Controller	69
5.4	Application Example	70
5.5	Motor Connections	75
5.6	Index	76

1.1

Step Motor Controller SMC30



Step Motor Controller Type SMC30 is an easy-to-use unit for accurate control of step motors.

Type SMC30 can be used either as a stand-alone unit or together with a terminal or PC via the Controller's RS232C/V24 interface.

The SMC30 is equipped with several inputs and outputs which offer the user great flexibility for configuring the Controller for various applications such as controlling milling machines, drills, handling equipment, etc. — where rapid and accurate motion control is required in a compact, economic system.


Controller SMC30 is available in two different models - SMC30B and SMC30C - both of which are based on the Bipolar Chopper principle and operate with driver voltages of 150V. SMC30B provides adjustable motor currents from 0 to 6 Amp/phase while Type SMC30C offers phase currents from 0 to 12Amp. In both models, the Motor Driver is short-circuit protected.

All User Outputs are protected against short-circuits and inductive transients.

The Controller can be mounted in a 19" rack or directly surface mounted.

Features:

- Mains Powering, 230V AC.
- Motor Torque up to 12Nm.
- Chopper-driver 150V with continuous adjustment of motor phase current (0-6/0-12A per phase).
- Thermally protected.
- EMC-screened.
- RS232C/V24 communication.
- Baud-rates: 110 - 9600 baud.
- Connection of up to 7 Controllers on same interface.
- Simple programming.
- Operating frequency up to 15kHz.
- 3 User Inputs.
- 6 Analogue/Digital Inputs.
- 1 Stop Input.
- 3 User Outputs (each 500mA).

**Front Panel:**

- "Power" Indicator
- Indication of running/stop status
- Indication of power consumption
- Indication of overheating
- Indication of short-circuited motor output
- Indication of short-circuited User Output
- RS232C Interface

Motor Output :

Either a 2-phase or 4-phase step motor can be connected to the Controller. The output is short-circuit protected. The Motor can be controlled with a resolution up to 15.000 half/full steps per second.

Power Supply :

Type SMC30 is equipped with an integral mains power supply (115/230V AC).

User Inputs :

The Controller is equipped with 4 noise-protected inputs, 1 of which is reserved as a Stop Input for instantaneously stopping motor movement. The 3 remaining Inputs can be used, for example, for connecting inductive sensors or for synchronisation with other controllers.

The Inputs accept voltages in the range 5-30V.

The User Inputs are optically isolated from other Controller circuitry.

Interface :

The Controller's RS 232C Interface enables the SMC30 to be connected to a computer or terminal. Up to 7 controllers may be connected on the same interface bus.

Module Interface :


The Controller's Module Interface consists of 2 optically isolated terminals which are used to connect the Controller to external modules such as a Keyboard/Display Module, Input/Output modules, etc.

CW and CCW End-of-Travel Inputs :

These Clockwise and Counter Clockwise End-of-Travel Inputs are used for applications where it is essential that motor movement does not exceed pre-defined limits. Activation of one of these Inputs results in instantaneous stop of motor movement. The CW and CCW Inputs are optically isolated from other Controller circuitry.

1.2

Controller Connections



Rear Panel:

- 230V AC Mains Power
- Motor Connection
- Module Interface
- 3 User Outputs
- 4 User Inputs
- CW and CCW End-of-Travel Inputs
- 6 Analogue/Digital Inputs
- RS232C Interface (secondary)
- Set-up of Communication Parameters, etc.
- User Supply 5-30VDC/500mA

User Outputs :

The Controller is equipped with 3 outputs which can be used for controlling small DC motors or for synchronisation with other control units.

Each User Output has a maximum rated output current of 500mA and operates in the range 5-30V.

All User Outputs are optically isolated from other Controller Circuitry. In addition, the Outputs are short-circuit protected.

User Supply Output :

For powering sensors, magnetic valves, etc., the Controller is equipped with a User Supply Output on the rear panel. The supply can be adjusted to give a supply voltage of either 5VDC, 24VDC, or continuously adjustable in the range 5 to 30VDC.

The Supply provides a rated output current of 0.5A regardless of the selected voltage.


Analogue Inputs :

The Controller is equipped with 6 Analogue Inputs which can be read via a set of software commands. This enables the motor top rate, for example, to be controlled by application of a voltage to one of the 6 Analogue Inputs.

A voltage in the range 0 - 5.10V, may be applied to the Analogue Inputs. The Inputs are protected against short-duration overloads up to 45V.

2.0


Block Diagram



The block diagram above shows the individual elements of the Controller.

This Chapter deals with the elements and functions of the Controller in terms of hardware. For a description of software functions, see Chapter 4, which details the complete set of software commands, for example for activation of the User Outputs.

Note that all Inputs and Outputs are optically isolated, with the exception of the Analogue Inputs which are not optically isolated from the microprocessor.



General

Controller Type SMC30 is equipped with an integral power supply for powering from AC mains supplies. The Controller's power supply also provides a User Supply Output for powering external devices. This supply can be adjusted to 1 of 3 settings (see above illustration).

If the switch is set to position 1, the supply provides a fixed voltage of 5VDC. If the switch is set to position 2, the supply provides a fixed voltage of 24VDC. In position 3, the supply provides a continuously adjustable voltage in the range 5 to 30VDC.

Regardless of the voltage selected, the User Supply provides a continuous maximum rated output current of 0.5A. If this value is exceeded, the power supply will reduce the voltage to ensure that no overload occurs.

The User Supply can therefore not be continuously short-circuited.

The User Supply and the Controller's internal supply voltage (150VDC) are externally available via 2 terminals.


The internal supply voltage can be used for powering other controllers in the motion control system. The red LED *Power Limit* on the front panel will be lit if power consumption exceeds the maximum rated consumption of 200W. If more than 200W is required, an external power supply can be connected.

In the event of voltage surge in the AC Mains supply, the Controller's overload protection circuitry will blow either the primary or secondary fuses. In this case, the Controller should be disconnected from the mains supply and the fuse replaced.

The primary and secondary fuses are located in the Mains Power Connector (see above).

2.1

Power Supply



External Power Supply

Controller SMC30 is equipped with a complete integral power supply to enable powering from AC mains supplies. This supply provides a continuous output of approximately 200W and handles peak loads up to 300W. If this limit is exceeded, the *Power Limit* LED on the Controller's front panel will be lit. In this case, an external power supply can be connected (see above illustration). It should be noted that the Controller reduces the motor phase current if the load exceeds 200W.

The capacity of an external power supply is determined by the motor speed and torque requirements.

JVL Industri Elektronik offers the following external power supplies:


PSU150-2 : 150VDC/200W
PSU150-4 : 150VDC/400W.

If a voltage of more than approximately 180V is applied to the 150V input, the Controller's overload protection circuitry will disconnect the applied voltage by blowing an internal fuse. This feature is intended to protect the Controller in extreme situations and if the internal fuse is blown, the Controller should be sent for service maintenance.

In the event of voltage surge in the AC Mains supply, the Controller's overload protection circuitry will blow either the primary or secondary fuses. In this case, the Controller should be disconnected from the mains supply and the fuse replaced. These fuses can be replaced by a user and are located in the Mains Power Connector on the rear panel.

2.2

Motor Connection



Motor Types

Various types of step motor are commonly available:

1. 2-Phase Bipolar (4 terminals)
2. 4-Phase Bi-/Unipolar (8 terminals)
3. 4-Phase Unipolar (6 terminals)-not suitable

Note that type 3 motors (Unipolar) are not suitable for operation with this Controller, which utilises the Bipolar principle. Note also that a bipolar system typically provides 40% more torque than a unipolar system.

2- or 4-phase motors can be connected as follows:

2-Phase Motors (4 terminals)

This type of motor can be connected directly to the Controller's output terminals.

The current supplied by the Controller may be maximally adjusted to the specified rated motor phase current.

4-Phase Motors (8 terminals).

This type of motor can be connected in one of two configurations:

1. Serial connection of phases.
2. Parallel connection of phases.

The choice of motor configuration is typically determined by the speed requirements of the system. For slow speeds (typically less than 1kHz), serial phase connection can be selected. For speeds greater than 1kHz, parallel phase connection can be selected.


Serial Connection of Motor Phases:

Serial connection of motor phases provides the same torque as a parallel phase configuration at speeds up to 1kHz but requires only half the motor current. This can influence the choice of Controller, enabling a Controller with a lower rated motor phase current to be used (see above illustration).

When the phases of a 4-phase step motor are connected in series, the rated phase current of the motor should be divided by a factor of 1.41. If for example, the rated current is specified as 4.2A, the Controller must be adjusted to provide a maximum phase current of 3A.

Parallel Connection of Phases

Parallel connection of motor phases provides greater output at frequencies above 1kHz compared with serial connection, but requires twice the phase current. This can influence the choice of Controller since it is necessary to select a Controller that can provide a greater output than that required with serial configuration (see above illustration). When the phases of a 4-phase step motor are connected in parallel, the specified rated motor phase current should be multiplied by a factor of 1.41. If for example, the rated phase current of a 4-phase motor is 4.2A, the Controller should be adjusted to provide a maximum phase current of 5.9A when the phases are connected in parallel.



It should be noted that the lower the self-inductance of a step motor the better, since this has a significant influence on the motor torque at high speeds. The torque is proportional to the current supplied to the motor, as follows:

$$\text{Current} \approx \text{Torque} \approx \frac{\text{Applied Voltage}}{\text{Phase Induction} \times \text{Frequency}}$$

The voltage applied by the Controller to the motor is regulated by the driver to provide the selected phase current.

In practice this means that if a motor with a large phase inductance (e.g. 100mH) is selected, the driver will not be able to supply the required phase current at high speeds (high frequencies) since the output voltage is limited.

Cabling

Controller Type SMC30B supplies motor phase currents in the range 0 to 6A and it is therefore recommended that 0.75 mm² cable (min.) is used to connect a motor to the Controller.


Controller Type SMC30C supplies motor phase currents in the range 0 to 12A and it is therefore recommended that 1.5 mm² cable (min.) is used to connect a motor to the Controller.

Cable lengths should not exceed 10m to avoid impedance loss.

Important !

To avoid noise emission from the motor cables, only screened cables should be used for connecting a motor to the Controller.

If screened cable is not used, electrical interference of other equipment may occur.



Step Resolution

The Controller enables either full-step or half-step control of the connected step motor to be selected. It is often advantageous to select half-step operation since this provides twice the resolution per motor revolution and can avoid the need for mechanical gearing.

Another advantage of half-step operation is that the resonance frequencies normally encountered with full-step operation are avoided. The resonance frequency of a step motor varies with load and results in complete loss of power at resonance.

With larger step motors, the resonance frequency will normally be outwith the operating range of the motor (the frequencies through which the motor is accelerated or decelerated).

The above illustration shows how half- and full-step operation are selected.

Overload Protection

The Controller's driver circuitry is overload protected. The driver output is automatically disconnected if the peak current exceeds the maximum Controller current by more than 20% for more than 2ms. A short-duration short-circuiting of any two motor terminals will not damage the Controller and will simply result in an overload indication on the *Overload* LED on the front panel. To reset the Controller in this case, the Controller supply voltage should simply be disconnected for a period of 5 seconds (minimum).

Note ! The Controller motor output is not protected against short-circuiting to ground (P-).

2.3

User Outputs

To provide maximum flexibility, Controller Type SMC30 is equipped with 3 inputs and 3 outputs which can be used for user-defined purposes.

A fourth input is used as a Stop Input.

All inputs are optically isolated from other Controller circuitry.

The Controller's User Inputs and Outputs must be powered externally.

User Outputs

SMC30's User Outputs enable auxiliary functions such as actuators and small motors to be controlled by the Controller.

These Outputs enable a step motor to be synchronised with peripheral equipment in the motion control system.

The User Outputs are software controlled and provide a maximum rated current of 500mA.


The Outputs are protected against inductive transients and are short-circuit protected.

If any of the User Outputs is short-circuited or the current exceeds 700mA, the "Overload" LED will be lit and the voltage is disconnected from the Output.

To reset the Controller in this case, the Controller power should be disconnected for a minimum of 5 seconds.


Each of the User Outputs is regarded as a connection to the + supply, i.e. if an Output is activated, the load must be applied between the output terminal and ground (see illustration below). with logic circuitry, a "pull down" resistor should be connected between each output terminal and ground. For TTL, this resistor should be 1kOhm; for CMOS a resistor of approximately 10kOhm can be used.


Connection of User Outputs



2.4

Clock Output





For use in motion-control systems where several step motors are operated synchronously, Controller SMC30 is equipped with a step-pulse Clock Output which outputs a voltage pulse for each motor step. The Clock Output can also be used for connection of a counter or similar equipment which is used to track motor position.

The electrical specification of the Clock Output is identical to the 3 User Outputs. The Clock Output provides a maximum rated output current of 500mA. Similarly, the Clock Output uses the same ground and supply as the other User Outputs.

The Output is protected against inductive transients and is short-circuit protected.

If the Clock Output is short-circuited or the output current exceeds 700mA, the "Overload" LED will be lit. In addition the voltage to the Clock Output will be disconnected.

To reset the Controller in this case, the Controller supply should be disconnected for a minimum of 5 seconds.

The Clock Output is regarded as a connection to the + supply, i.e. if the Output is activated, the load must be applied between the output terminal and ground (see illustration below).

To enable compatibility with logic circuitry, a "pull down" resistor should be connected between the output terminal and ground. For TTL, this resistor should be 1kOhm; for CMOS a resistor of approximately 10kOhm can be used.

2.5

User Inputs


Each of the Controller's User Inputs is equipped with a 1st-order low-pass filter which suppresses frequencies above 1kHz. This filter is used to ensure that electrical noise from step motors or other equipment in the motion control system does not influence the input signal.

It should be noted that the status of a User Input is undefined if no connection is made to the Input.

All of the User Inputs are optically isolated from other Controller circuitry. This means that the Input must be powered from an external supply (see illustration below).

Some inductive sensors have an open collector output. For sensors with an NPN output, an external resistor must be connected between the Input to the +supply. For PNP sensors, an external resistor must be connected between the Input and ground. It is recommended that a resistor of between 500Ohm and 5kOhm should be used depending on the supply voltage.

Connection of User Inputs



2.5

User Inputs

Input Hysteresis

All User Inputs are noise-protected and are compatible with common logic types: CMOS, TTL, etc.

The input hysteresis is dependent on the applied supply voltage as illustrated below.


Example:

Input 1 is used and the supply voltage is 24V.

As illustrated below, Input 1 is logic "1" when an input voltage greater than 13.3 VDC is applied. To set the output to logic "0", the input voltage must be reduced below approximately 5.3 VDC.

The tolerance on these voltages is $\pm 10\%$.


Input Voltage



See also Section 4.5 (User Interface) for details of User Inputs and Outputs.

2.6

Analogue Inputs



Analogue Input

The Controller is equipped with 6 Analogue Inputs which can be read using a set of software commands, as described in Chapter 4.

The Analogue Inputs enable, for example, the step motor speed to be controlled by application of an analogue voltage.

The Inputs are protected against short-duration overloads up to 45V.

Each time an Analogue Input is read, a total of 16 samples is made. These values are averaged to minimise the risk that a spurious noise pulse, for example from the step motor driver, influences a measurement.

The Analogue Inputs can also be used as conventional User Inputs (digital inputs), although without hysteresis (Section 2.5) and the Inputs are not optically isolated.


No special requirements are necessary to use the Analogue Inputs in this way, since at any time an Input can be used as an analogue input or as a User Input. See Chapter 4 - commands: $\pm A$, DA , $G\pm A$, JCA , NA , r , s , t , U , VA , W .

The Inputs accept voltages in the range 0V to 5.10V. The Controller uses an 8-bit A/D converter, providing a resolution of 256 steps. Each step thus corresponds to 20.0mV at the Input.

To avoid sampling errors, the analogue ground, AGND (see pin designations, Section 2.7) must be used with the 6 Analogue Inputs.

See Section 5.1, "Electrical Specifications", for further details.

Each Analogue Input is equipped with a 1st-order low-pass filter which suppresses frequencies above 10kHz.



CW and CCW End-of-Travel Inputs

In step motor motion-control systems it is often necessary to establish well-defined mechanical limits which under no circumstances must be exceeded by motor operation.

To enable such end-of-travel limits to be set up, the Controller is equipped with 2 inputs: *CCW* (Counter Clockwise) and *CW* (Clockwise).

Depending on the direction of motor rotation, activation of one of these Inputs will stop motor movement instantaneously.

CCW Input.


If the motor is rotating counter- clockwise, activation of the *CCW* Input (logic "1") will stop motor operation. The *CW* Input has no effect on motor operation during counter-clockwise rotation.

CW Input

If the motor is rotating clockwise, activation of the *CW* Input (logic "1") will stop motor operation. The *CCW* Input has no effect on motor operation during clockwise rotation.

Note that when activation of either the *CW* or *CCW* Input is used to stop operation, the motor is stopped instantaneously, regardless of any pre-set deceleration ramp.


Note also that program execution is not stopped, only motor operation.



To instantaneously stop program execution and thus motor operation, the Controller's Stop Input is pulled to ground. If the Input is thereafter deactivated, program execution and thus motor operation will continue and the contents of the position counter will be retained. It should however be noted that an instantaneous stop in this way will most probably result in the motor being in an undefined position since activation of the Stop Input does not take account of any pre-set acceleration/deceleration ramps. For further details, see Section 4.6, Motor Commands.


Connection of Motor and External Power Supply

Connector: DIN41612 version H



Pin Designations for External Facilities

Connector: DIN41612 version C/3




3.1

Interface Connections

The Controller Interface uses the widespread RS232C standard, which provides a great degree of flexibility since all Personal Computers and standard terminals have provision for using this communication standard. For operation of the Controller via an RS232C interface, the 3 standard RS232 connections Rx, Tx and Ground are used.


In general, interface cables should not exceed 10 metres in length but if a longer cable is required, the interface checksum facility should be used to ensure data integrity. See Section 3.5.

Controller Interface:



For communication with the Controller via a PC, the interface connections are illustrated in the following figures.


Connection between the Controller and an IBM AT or compatible :



3.1

Interface Connections

Connection between the Controller and an IBM XT/PS2 or compatible :



3.2

Interface Addressing


The Controller can be configured to respond to all communication on the interface ("point-to-point" communication). In addition, it is possible to connect up to 7 Controllers on the same interface bus, i.e. "multipoint" communication. For multipoint communication the Controller DIP switches must be set to assign a unique address to each controller on the interface bus. In this way, each controller only responds to interface commands which are preceded by its preset address. To configure Controllers for multipoint addressing, the DIP switch marked *Tx-PD* on one (and only one) of the Controllers must be set to *ON*. For the remaining Controllers in the multipoint configuration, *Tx-PD* must be set to *OFF*. For point-to-point communication, *Tx-PD* is set to *ON* on the Controller.

In order to ensure data integrity during communication, it is recommended that the interface checksum facility is used. Checksum is enabled by setting the CHS DIP-switch to *ON*. For further details, see Section 3.5.

The DIP switch settings for configuring the interface address on Controllers are given in the following table:

A0	A1	A2	Address	Protocol
0	0	0	-	Point to point
1	0	0	1	Multipoint
0	1	0	2	Multipoint
1	1	0	3	Multipoint
0	0	1	4	Multipoint
1	0	1	5	Multipoint
0	1	1	6	Multipoint
1	1	1	7	Multipoint

IMPORTANT! : If the address switch settings are changed, the Controller must be reset by switching off and on the power for the new address to take effect.




3.3

Communication Rate

Baud Rates of 110 to 9600 Baud can be selected for communication using the Controller's RS232C interface. The Baud Rate is configured by setting 3 DIP switches, as shown in the following table.

B0	B1	B2	Baud Rate
0	0	0	110
1	0	0	150
0	1	1	300
1	1	1	600
0	0	0	1200
1	0	0	2400
0	1	1	4800
1	1	1	9600



IMPORTANT! : If the Baud Rate setting has been changed, the Controller must be reset by switching the power off and on again for the new Baud Rate to take effect.

Note that the Baud Rate must also be set to the selected value on the PC or terminal used for communication with the Controller. In addition, the communication protocol should be set as follows:

(1 start bit) 7 data bits odd parity 1 stop bit

() A start bit is always used with RS232C/V 24 protocol.

3.4

Command Syntax

Interface communication with the Controller must fulfill the following command syntax:

Address **Command** **Argument** **Checksum** **Return**

Address : It is only necessary to specify the Controller Address if more than 1 Controller is connected to the interface (multipoint configuration). The specified Address is a value in the range 1 - 7.

Command : The command character(s) to be transmitted to the Controller. See the Software Description in Chapter 4 for details of the Controller commands.

Argument : The command arguments if any. Certain commands such as the *K* (Kill) or *Z* (Smooth Stop) commands have no argument. (See Software Description).

Checksum : The checksum can be used if long communication lines are used between the Controller and PC or terminal. The checksum ensures integrity of data transmission on the interface. If an error occurs, an error message (*E1*) will be received. It is then necessary to re-transmit the command string (see following page).

Return : ASCII character 13. The return character tells the Controller that the command string is complete and interpretation of the command can be initiated.

3.5

Checksum Facility

Electrical noise from sources such as electrical motors is a common occurrence in industrial applications. This noise can be completely random in nature and despite effective electrical filtration electrical noise cannot be eliminated completely. In applications where it is vital to ensure that the system operates precisely as required, it is therefore essential to select a communication rate (Baud Rate) that is not too high. Moreover, the interface cable used to connect the Controller to a PC or terminal should not exceed 10m in length. A typical command string used for interface communication with the Controller will be of the following form:

1A3%

In the above example, multipoint communication is used and the command is being transmitted to a Controller which has address 1. The command is being sent to activate output number 3 (A3). The communication checksum for transmission of a command is determined as follows. First, the ASCII value of each character in the command string is determined. The ASCII values are then summed and the result divided by 128. The integer-result of the division is discarded, while the remainder is used as the checksum. Calculation of the checksum for the above example is thus as follows:

Address character 1 = ASCII 49
Command character A = ASCII 65
Argument character 3 = ASCII 51


Sum + remainder = (49+65+51)/128

Checksum = Remainder * 128

If an error occurs during transmission of the command string, the checksum will be incorrect and the Controller will return the error message "E1" indicating that the Controller could not interpret the received command string. The command must then be re-transmitted. If the Controller continues to transmit "E1", the interface Baud Rate should be reduced or a shorter cable used to connect the computer to the Controller.


The Checksum facility is activated by setting the CHS DIP-switch to ON.

IMPORTANT! : If the checksum switch setting is changed, the Controller must be reset by switching the power off and then on for the new setting to take effect.



3.6

Module Interface



Controllers Type SMC30 can be connected to external modules such as a, input/output-module, keyboard/display-module etc.

Connection to external modules is made via the Controller's RS485 serial interface using the two terminals marked "A" and "B".

All external module functions are controlled via this interface. Up to 31 modules (and at least 1 motor - controller) can be connected to the interface bus.

The RS485 Interface offers several advantages in that the interface operates with a balanced output and has low impedance. In addition, the Controller's RS485 interface is optically isolated from other Controller circuitry.

The RS485 Interface is protected against transients on the cable connecting the Controller to external modules. These factors enable communication at long distances despite the presence of electrical noise.

It is recommended that twisted-pair cable is used for connection between the Controller and other modules on the interface.

If the communication distance between 2 units in a system exceeds 25 metres, the DIP switch marked *TERM* must be set to the *ON* on those units which are located more than 25 metres apart.

See the User Manual for the module in question for details of DIP switch settings.

Module Addresses:

In communication systems where several modules are connected together, each unit must be assigned a unique address in the range 1 to 31.

The above illustration shows how addresses in a typical system are set.

Note that care must be taken to ensure no two modules use the same address. If the module addresses are not unique, the Controller will terminate program execution and an error message will occur.

Note that the Controller's address is the same as that used for RS232 communication. (See Section 3.2.)

The address of each module should be set in accordance with the instructions given in the respective module's User Manual.

4.1 General Aspects of Controller Software

Before the individual software commands are described in detail, it is necessary to describe some general aspects of the Controller software structure.

The Controller is equipped with 2 types of storage memory, both of which are accessible to the user. These are used for storing programs and operational parameters sent from a computer or terminal.

The first of these storage memories is referred as the "*working memory*" in the following pages. The Controller's working memory is used during connection to a computer or terminal. The working memory is a volatile memory; its contents are deleted when the Controller is switched off. The working memory can also be used for storing instructions during programming.

The second of the Controller's storage memories is an EPROM, i.e. a non-volatile memory which retains its contents when the Controller is switched off. This is referred to as the Controller's "*permanent memory*" in the following description. The Controller's permanent memory is intended for use when the Controller is used as a *Stand alone unit*, i.e. is not connected to a computer or terminal. Use of the permanent memory enables the Controller to begin execution of pre-programmed instructions without requiring connection to an external PC or terminal.

Permanent memory can also be used if the Controller is connected to a PC or terminal. In this case it is typically used to store frequently used program sequences which can be pre-programmed and downloaded to the permanent memory.

Position Counter.

The Position Counter is a storage register which keeps track of the motor's current position during operation. The Position Counter can be reset by the *I* - (Initialise) or *H* (Home) command (see Sections 4.3 and 4.4). The Position Counter's contents can also be read or changed using the commands *V1* and *f[±n]*.

When the Position Counter reaches its maximum value of +8,388,607 or -8,388,608, the motor stops automatically.

Command Descriptions.

The following pages (Sections 4.3 to 4.6) describe each of the commands used for programming the Controller.

To avoid any misunderstanding regarding the use of the commands and command syntax, the following text convention should be noted:

Each command is described by one or more command characters followed by a word in parentheses. The actual command used to program the Controller using the command syntax consists of the characters, not the word which is included in the description as a mnemonic. Note that many of the command descriptions include examples of the command string.

Almost all commands are followed by one or more parameters: either a value, or a plus (+) or minus (-) sign. It is important that the specified numeric value is within the permitted range since the Controller will not interpret parameters outwith the allowable range.

See also Section 3.4 for details of the Controller command syntax.

4.1 General Aspects of Controller Software

Operating Modes.

The Controller can be operated in 1 of 3 modes:

1) *Standby Mode.*

Standby Mode occurs after a *K* (Kill), *Z* (Smooth Stop) or *PX* (Program Exit) command, and after execution of a program.

2) *Programming Mode.*

This mode is used when a program is read in to the Controller or to edit an existing program. Use the *PO* (Program) or *PE* (Program Enter) command to set the Controller to Programming Mode.

3) *Execute Mode.*

The *E* (Execute) command is used to execute the program currently in the Controller's working memory.

Program execution stops when all commands have been executed or if interrupted by a *K* or *Z* command. Thereafter, the Controller returns to Standby Mode.

Programming.

When creating a new program, the first command is always *PO*, i.e. the Controller is set to Programming Mode. The actual program commands can then be keyed-in.

Once all the required commands have been programmed, the *E* command is used to switch the Controller to Execute Mode and the program is executed. To store the program in permanent memory, the *M* (Memory save) command can be used once program execution is complete. Programming Mode can also be interrupted using the *PX* (Program Exit) command, in which case the Controller will be set to Standby Mode.

A typical sequence for programming the Controller is as follows:

		<i>Mode:</i>
1)	Controller switched on.	<i>Standby</i>
2)	<i>PO</i> (Program) command keyed-in.	<i>Program</i>
3)	Required sequence of program commands keyed-in.	<i>Program</i>
4)	<i>PX</i> (Program Exit) command keyed-in, after which the Controller is set to Standby Mode.	<i>Standby</i>
5)	<i>E</i> (Execute) command keyed-in	<i>Execute</i>
	* The entire program is then executed, unless an interrupt occurs via <i>K</i> (Kill) or <i>Z</i> (Smooth Stop) command.	
6)	The program can be stored in permanent memory by keying-in the <i>M</i> - (Memory Save) command.	<i>Standby</i>

It should be noted that at power-up, the error message E1 will probably be received when communication is first established between the Controller and a PC/terminal. This is due to transients which arise on the interface cable when the computer or Controller is switched on.

4.1

Controller Response

Each time the Controller receives a command or query via the interface, it responds to the PC or terminal with a short response string. The syntax of the response string is as follows:

Reply Code **Argument** **Checksum** **Carriage-Return**

Reply Code - The Reply Code is the actual response to the received command and is one of the following:

- Y** = (Yes) The command has been received and will be, or has been, complied with.
- B** = (Busy) The Controller is busy with program execution and is not ready to receive the command or query.
- R** = (Ready) The Controller is ready to execute a command or respond to a query.
- V** = (Verify) Position or User Input/Output status. This message will only occur if the Controller is queried about the status. See the descriptions of the V1 and V2 commands in Sections 4.3 and 4.5 for further details.
- E** = (Error) An error has been found in the received command and the Controller is not able to comply with the command. This response returns an argument which indicates the type of error as follows:
 - E1** - Parity Error after receiving one or more characters. Checksum Error. The received command string was too long.
 - E2** - The command argument is too long or is unnecessary.
 - E3** - The working memory is full.
 - E4** - Unknown command or the Controller is unable to comply with the received command.
 - E5** - The Position Counter has exceeded its maximum of -8,388,607 or +8,388,607 steps, the motor has been stopped. Error in Parameters (R, S, T).
 - E6** - An error occurred during transmission to or from the Controller's Permanent Memory.

Argument - An argument to the response will only occur with E (Error) or V (Verify) messages. The argument consists of 1 to 7 characters.

Checksum - A checksum value is only included in the response string if the checksum facility is enabled via the DIP switch setting on the Controller (set to *ON*).
See the description of the checksum facility in Section 3.5 for further details.

Carriage-Return - Terminates the response string. ASCII-value 13.

4.2

Command Overview

System Commands :

E	(Execute)	Starts program execution.
f [±nnnnnnn]	(Forcing Pos.)	Reads in new position.
F	(Feedback)	Status query to the Controller.
I [n]	(Initialize)	Resets Controller Registers (software reset).
K	(Kill)	Stops execution of current program.
M	(Memory)	Saves working program in Permanent Memory.
PE	(Program Enter)	Sets the Controller to Programming Mode without erasing existing program in working memory.
PO	(Program)	Sets the Controller to Programming Mode. This command erases any program instructions already in working memory.
PX	(Program Exit)	Exits Programming Mode. Returns to Standby Mode.
Q	(Query)	Displays the program currently stored in Working Memory.
TP	(Temperature)	Returns the current temperature of the Controller.
V1	(Verify)	Returns the Position Counter value.
X	(Recall)	Loads program from Permanent Memory into Working Memory.
Z	(Smooth Stop)	Stops program execution slowly taking account of deceleration ramp.

Motor Commands :

[±nnnnnnn]		Relative positioning given by direction of rotation (+/-) and number of steps.
±A [n].[n1-n2]		Relative positioning controlled by voltage at Analogue Input.
CR [nnnn]	(Current Ramp)	Determines motor current during acceleration.
CS [nnnn]	(Current Start)	Determines motor current when stationary.
CT [nnnn]	(Current Top)	Determines motor current at top speed.
g [±]	(Velocity)	Continuous operation forward/reverse.
G [±nnnnnnn]	(Goto)	Absolute positioning.
G±A [n].[n1-n2]	(Goto)	Absolute positioning controlled by voltage at Analogue Input.
H [±]	(Home)	Resets motor and electronic circuitry.
N [n1n2.n3n4]	(Input Setup)	Starts/stops motor in accordance with User Inputs.
NA [p1.p2]	(Input Setup)	Starts/stops motor in accordance with Analogue Inputs.
R [nnnnn]	(Ramp)	Acceleration/deceleration parameter (1-10000 steps).
RT [nnnn]	(Ramp Time)	Acceleration/deceleration parameter (0.01-10 seconds).
RS [nnnnn]	(Ramp Slope)	Acceleration/deceleration parameter (10-30000 step/s ²).
S [nnnn]	(Start Rate)	Minimum speed.
T [nnnnn]	(Top Rate)	Maximum speed.
r [n1.n2]	(A/D Ramp)	Same as R, controlled by voltage at Analogue Input.
s [n1.n2]	(A/D Start Rate)	Same as S, controlled by voltage at Analogue Input.
t [n1.n2]	(A/D Top Rate)	Same as T, controlled by voltage at Analogue Input.
VR	(Verify Ramp)	Returns the current acceleration/deceleration parameter.
VS	(Verify S. Rate)	Returns the current Start Rate parameter.
VT	(Verify T. Rate)	Returns the current Top Rate parameter.

4.2

Command Overview

(continued)

User Interface :


A [n]	(Activate)	Activates one of the outputs.
C [n]	(Clear)	De-activates one of the outputs.
U [n]	(Until)	Repeats program(segment) until a specified input is activated.
VA [n]	(Verify Ainput)	Returns (measures) voltage at one of the 6 Analogue Inputs.
VA	-	Returns (measures) the logic levels of the Analogue Inputs.
V2	(Verify)	Returns status of user inputs and outputs.
W [n]	(Wait for)	Pauses program execution until a specified input is activated.

Flow Commands :

D [nnn]	(Delay)	Wait a specified time.
DA [n].[n1-n2]	(Analog Delay)	Wait a specified time controlled by analogue voltage.
J [n1]	(Jump)	Unconditional jump to a specified program line.
JC [n].[n1]	(Jump Cond.)	Conditional jump to a specified program line.
JCA [p].[n1]	(Jump Cond.)	Conditional jump to a specified program line when specified voltage is applied to Analogue Input.
JS [n1]	(Jump Sub)	Unconditional jump to sub-routine.
RET	(Return)	Return from sub-routine.
L [nnn]	(Loop)	Repeat program segment a specified number of times.

Extended Command Set

+ - / *		Arithmetic operators: addition, subtraction, division, multiplication.
VR[0-510]	(Verify)	Return contents of User Register.
I[5-7]	(Initialize)	Initialize User Registers.
con=[n]	(Convert)	Specify conversion between current and a user-specified measurement unit.
PRINT[n1.n2.n3]	(PRINT)	Print Register contents to external module.
IF [p1 m p2]	(IF)	If expression specified by command arguments is true, execute next line.
INPUT[n1.n2.n3]	(INPUT)	Read in data from external module to Register.
AO[a].[o]	(Activate)	Activate flag in external module.
CO[a].[o]	(Deactivate)	Deactivate flag in external module.



4.3

System Commands

E (Execute) Starts program execution. The Execute command can also be used to complete a programming sequence. The command can be used when the Controller is either in Standby Mode or Programming Mode.

f+/-[nnnnnnn] (Forcing pos.) Assigns a specified value to the Position Counter. The position can be specified in the range -8,388,607 to +8,388,607, both values included. The command can be used when the Controller is in Standby Mode and in Programming Mode.

Example:

f+100 assigns a value of +100 to the Position Counter.

F (Feedback) Status Query to the Controller. 1 of 3 responses will occur.

- 1) If the Controller is ready to receive and execute commands, the Status Query response is R (Ready).
- 2) If the Controller is busy, the Status Query response is B (Busy).
- 3) If the motor has been stopped automatically because of an overflow in the Position Counter, the Status Query response is E5 (Error 5).

I [1-3] (Initialize) The Initialize command is used to reset either the Position Counter and/or User Outputs.

I1 = Resets the Position Counter only.

I2 = Resets the User Outputs only.


I3 = Resets both the Position Counter and User Outputs.

K (Kill) The Kill command has the highest priority since it stops program execution regardless of motor movement. The Kill command is effective immediately, i.e. as soon as the command is issued, the Controller is set to Standby Mode. To begin program execution once more, a new Execute command must be used. The program will start from the beginning. It is often necessary to use the H (Home) command before starting a new execution of a program since the motor position will be arbitrary owing to the instantaneous stop resulting from the Kill command.

4.3

System Commands

M
(Memory Save) To enable completed programs to be permanently stored after the power has been switched off, the Controller is equipped with a permanent, non-volatile memory. The Memory Save command is used to store the contents of the Controller's volatile working memory in the non-volatile permanent memory. Only 1 program can be stored in permanent memory at a time. If the *REC* DIP switch is set to "ON", the program stored in permanent memory is automatically recalled and executed when the Controller is switched on.



PE
(Program Enter) The Program Enter command is used to set the Controller to Programming Mode without erasing any existing instructions in the working memory. This command is primarily used when editing a program during development.

PO
(Program) The Program command sets the Controller to Programming Mode, i.e. so that the Controller is ready to receive programming instructions. Each time the Program command is used, the contents of the Controller's working memory are reset, erasing any existing instructions. (See also the Program Enter command above and the description of the Program command at the beginning of this Chapter.)

PX
(Program Exit) The Program Exit Command is used to exit Programming Mode and set the Controller to Standby Mode. A program can then be executed or a new program keyed-in.

Q
(Query) The Query command returns the program currently stored in working memory, including run-time parameters. If a printout of the program in permanent memory is required, the X (Recall Program) command should be used prior to the Query command. Note that use of the Recall Program command will erase the contents of the Controller's working memory.

4.3

System Commands

- TP** Returns the current temperature of the Controller.
(Temperature) The Temperature command can be used to verify that the Controller is operating within its specified temperature range of 0-50°C. If, under "worst-case" conditions, a temperature greater than approximately 60°C is registered, ventilation of the Controller must be improved.
- V1** The Verify Position command is used to read the contents of the Position Counter.
(Verify Pos.) The value returned is relative to 0, the Home position. (See also the Home command).
- X** The Recall Program command is used to read the program (if any) stored in the Controller's non-volatile, permanent memory and load the program into the working memory. This command can be used advantageously if, for example, a program is to be executed at regular intervals. A Recall Program command is then followed by an Execute command, thus starting program execution immediately.
(Recall Prog.) Note that each time the Recall Program is used to load a program from permanent memory in to working memory, any instructions in the Controller's working memory will be erased.
- Z** The Smooth Stop command has the same function as the Kill command.
(Smooth Stop) except that the motor is decelerated in accordance with the specified R, S, T parameters. The Smooth Stop command is thus used to ensure that the motor does not stop at an undefined position. (See also the *K* (Kill) command).

4.4

Motor Commands

+/- [nnnnnnn] (Relative) The Relative command is similar to the Goto command. Instead of positioning the motor relative to the 0 (Home) position, the Relative command positions the motor relative to its current position. The command specifies the direction (+ or -) and the number of steps the motor is moved.
The number of steps can be specified in the range 1 to 8,388,607 steps.

Example :


+15 , A Relative positioning command of +15 will advance the motor 15 steps relative to its current position.

±A [n].[n1-n2] This command is used to move the motor a specified number of steps, using the value of an analogue voltage.
The command parameter "n" specifies which Analogue Input (1-6) is used for controlling the movement. The parameters "n1" and "n2" specify the step interval, where n1 indicates the number of steps corresponding to an input voltage of 0V, and n2 indicates the number of steps corresponding to an input voltage of 5.1V. n1 and n2 can be specified from 1 to 65000 steps.

Example :

+A1.100-1000

The above command advances the motor (indicated by +) 100 steps if a voltage of 0V is applied to Analogue Input 1, and 1000 steps if a voltage of 5.1V is applied. For voltages between 0V and 5.10V a linear interpolation is used to determine the number of steps the motor is moved (see figure below).



4.4

Motor Commands

The current supplied to a stepper motor can be adjusted to specified values for standby, acceleration/deceleration, and top speed. Normally only a small current is required when the motor is stationary since the static inertia of a typical stepper motor is much less than the inertia while the motor is rotating, depending on the speed range of the motor.

The torque of a stepper motor is directly proportional to the applied current, up to the specified phase current (see the specifications for a given motor).

If the nominal current is exceeded, the motor will overheat and only very little increase in torque will result.

The following 3 commands are used to specify the current supplied to the motor. The commands can be used at any point in a program. All 3 commands can be specified and changed continuously throughout a program.

If any of the commands is omitted, the respective parameter assumes a default value of 1000mA.

CS [0-12000] (Current Standby)

Determines motor current when the motor is stationary.

CR [0-12000] (Current Ramp)

Determines motor current during acceleration/deceleration.

CT [0-12000] (Current Top)

Determines motor current at maximum speed.

Note that all 3 parameters can only be specified in the range 0 to 6000 mA for Controllers Type SMC30B.

Example:

(Program)

```
.  
CS500   Sets motor Standby Current to 500mA (0.5A).  
CR6000  Sets motor Ramp Current during acceleration/deceleration to 6000mA (6A).  
CT4000  Sets motor Top Current to 4000mA (4A) at top speed.  
+100    Advances the motor 100 steps.  
CT5500  Sets new motor Top Current to 5500mA (5.5A).  
. .
```

4.4

Motor Commands

g+/-
(Velocity Mode) The Velocity Mode command is used to move the motor continuously in a specified direction.
The command is followed by a + or - parameter which specifies the direction of movement. To stop the motor once the Velocity Mode command has been used, a Z (Smooth Stop) or K (Kill) command must be used.
If the N (Input Setup) command is used before the $g\pm$ command, the conditions specified by the N command can also stop the motor. (See the description of the Input Setup (N) command for further details.)
It should be noted that the Position Counter is updated while the Velocity Mode command is executed. The command can only be used when it is included in a program.

G+/- [nnnnnnn]
(Goto) The Goto command is used for absolute positioning of a stepper motor.
The specified parameter value refers to the Position Counter and can be specified in the range -8,388,607 and +8,388,607.

G±A [n].[n1-n2]
(Analog Goto) The Analog Goto command is used for absolute positioning of a motor motor (similar to the $G\pm[n]$ (Goto) command) but the required position is determined by the analogue voltage applied to a specified Analogue Input. The "n" command parameter specifies which Analogue Input (1-6) is used for the control signal. Parameters "n1" and "n2" specify the required positions corresponding to applied voltages of 0V and 5.10V respectively. The specified position can be set in the range +0 to +65000.
See also the $\pm A$ command.

Example:

G±A2.0-800

The above example moves the motor to position +0, if a voltage of 0V is applied to Analogue Input 2, and to position +800 if the applied voltage is 5.10V.

For applied voltages between 0 and 5.10V a linear interpolation between positions +0 and +800 is made.

H+/-
(Home) The Home command enables an electrical and mechanical reset of the system to a pre-defined reference position. As soon as the Controller receives the Home command, the motor will move in the specified direction (either $H+$ or $H-$).
As soon as the *EOT* (End of Travel) input becomes low, the motor will stop. The motor is then at its reference position. The speed at which a reset occurs is determined by the S (Start Rate) command.
After execution of a Home command, the Position Counter is reset to "+0".

4.4


Motor Commands

N [n1n2.n3n4]
(Input setup)

The Input Setup command enables a motor to be started or stopped using control signals at the User Inputs.

The Input Setup command itself does not start or stop the motor. It only determines how the next motor command $\pm[n] / g[\pm] / G\pm[n]$ will be interpreted and executed. Thereafter the Input Setup command is inactive until a new Input Setup command is executed. To subsequently start or stop the motor using the control signal at a User Input, a new Input Setup command must precede the new motor command.

Command Syntax:



n1: Specifies the User Input (1-3) used to start the motor.

n2: Specifies the User Input (1-3) used to stop the motor.

n3: Refers to n1 in that n3 determines the logic level to be applied to the specified User Input in order to start the motor. If n3 is set to 0, the motor will start when logic level 0 is applied to the specified User Input.

If n3 is set to a value between 2 and 9, the start function will be inactive and the motor will start immediately.

n4: Refers to n2, in that n4 determines the logic level to be applied to the specified User Input in order to stop the motor. If n4 is set to 1, the motor will stop when logic level 1 is applied to the specified User Input.

If n4 is set to 0, the motor will stop when the level changes from logic 1 to logic 0.

If n4 is set to a value from 2 to 9, the stop function will be inactive and the motor will only be stopped a motor command requires it.

(continued on following page)

4.4

Motor Commands

(continued)

N [n1n2.n3n4]
(Input setup)

When the Input Setup command is used for a movement sequence, the Position Counter is updated normally.

While the motor is moving, a *Z* (Smooth Stop) or *K* (Kill) command can be used to stop the motor. Program execution can also be halted using a *K* (Kill) or *Z* (Smooth Stop) command while the Controller is waiting for a start signal from a User Input.

Example 1:

The command N13.01 followed for example by a *g+* command will start the motor when User Input 1 attains a voltage of logic 0. Note that it is a logic level 0, and not a change from "1" to "0" that activates a start.

The motor will move according to the specified parameters and run at normal speed until a voltage corresponding to logic "1" is applied to User Input 3. Thereafter the motor will decelerate until it stops, and the next program command is executed.

Example 2:

The command N21.10 followed for example by a *+10000* command will start the motor when User Input 2 is logic "1" and operate at normal speed for 10000 steps (including deceleration ramp), or until a change from logic 1 to logic 0 occurs at User Input 1.

The motor will then decelerate and the next program command is executed.

Example 3:

The command N11.19 followed for example by a *G+3500* command will start the motor when User Input 1 becomes logic "1" and stop when position +3500 is reached. The motor will operate in accordance with the parameters specified by the *R*, *S* and *T* commands.


4.4

Motor Commands

NA [p1.p2] This command enables start/stop control of the motor via control signals at (Analog Input setup) the analogue inputs. The principle of the Analog Input Setup command is the same as the Input Setup command, N [n1n2.n3n4].

The 2 command parameters (p1 and p2) specify start and stop conditions respectively. The Analog Input Setup command itself does not start or stop the motor. It only influences how the next motor command $\pm[n]$ / $g[\pm]$ / $G\pm[n]$ will be interpreted and executed. Thereafter the command is inactive. To subsequently start the motor again using control signals at an Analogue Input, a new Analog Input Setup command must precede the new motor command.

The complete syntax for the Analog Input Setup command is as follows:



p1: If the start conditions are fulfilled, the motor is started. If p1 is assigned the character X, an unconditional start is defined, and the motor will start immediately the motor command is executed.

p2: If the stop conditions are fulfilled, the motor will be stopped. If p2 is assigned the character X, an unconditional stop is defined and the motor will operate until the specified motor command ($\pm[n]$, $g\pm$, $G\pm[n]$) requires it to stop.

a1: Specifies the Input used for the start control signal. a1 can be specified in the range A1 to A6, corresponding to Analogue Inputs 1-6.

a2: Specifies the Input used for the stop control signal. a2 can be specified in the range A1 to A6, corresponding to Analogue Inputs 1-6.

n1: Specifies the Start Reference Value. The Reference Value is compared with the measured voltage at the specified start Input (a1). The Start Reference Value can be set in the range 0 to 255.

n2: Specifies the Stop Reference Value. The Reference Value is compared with the measured voltage at the specified stop Input (a2). The Stop Reference Value can be set in the range 0 to 255.

m: The operator for comparison between the Reference Value and the measured value at the input(s). To start/stop the motor when the voltage at the respective analogue input is less than the Reference Value, the operator should be specified as "<". To start/stop the motor when the applied voltage is greater than the Reference Value, the ">" operator is specified.

4.4

Motor Commands

(continued)

NA [p1.p2]

(Analog Input setup)

Since n1 and n2 are specified as values in the range 0-255 and the voltage measured at the Analogue Inputs is in the range 0-5.10V, a conversion must be made when specifying n1 and n2, either by converting the Reference values to a voltage or vice versa. The conversion is made as follows:

$$V_{ref} = 0.02 \times n \quad \text{or} \quad n = 50 \times V_{ref}$$

Example:

If a Reference Value of 1.20V is required, n should be specified as:

$$n = 50 \times 1.2 = 60$$

Program Example 1:

```
.  
.   
NAA1<60.A6>100  
+10000  
.
```

In the above program example, the motor is started if the applied voltage at Analogue Input 1 is less than 1.2 Volts (see conversion example above). Otherwise nothing occurs. When the motor is running, it is stopped either after completion of the 10000 steps or when the voltage at Analogue Input 6 is greater than or equal to 2V (n2=100).

Program Example 2:

```
.  
.   
NAX.A5>220  
G+100000  
.
```

The parameter specification X indicates that the start condition is inactive and the motor will therefore start immediately. Thereafter the motor will stop when position +100000 is reached or if the applied voltage at Analogue Input 5 is greater than or equal to 4.4V (n2=220).

The K (Kill) and Z (Smooth Stop) commands can be used to interrupt program execution.

4.4

Motor Commands

In contrast to a normal DC motor (which is "Self-commutating"), a stepper motor is electrically commutated. That is, a stepper motor is driven by magnetic fields which are controlled electronically. When the motor is loaded, the magnetic fields will eventually not be powerful enough to continue to turn the rotor. The motor will stop, but the electronics will continue to move the magnetic fields at the same speed. It is therefore important that a motor is accelerated and decelerated at appropriate rates, in order for the magnetic fields to drive the rotor.

Similarly a stepper motor has a maximum speed and if this is exceeded the motor can no longer provide the same power and will simply stop.

There are 3 basic parameters which should be considered:

S [16-2000] (Start Rate steps/second)

The Start Rate is the speed at which the motor is started. If it is set too high, the motor will simply stop at an arbitrary position. The Start Rate can be set in the range 16 to 2000 steps/second. The default Start Rate is 100 steps/second.

T [16-15000] (Top Rate steps/second)

The Top Rate specifies the maximum speed of the motor. If it is set too high, the motor will be unable to provide enough power and will stop at an arbitrary position. The Top Rate can be set in the range 16 to 15000 steps/second. The default Top Rate is 1000 steps/second.

R [1-10000] (Ramp) / **RT [1-1000]** (Ramp time) / **RS [10-30000]** (Ramp slope)

This value specifies how the motor is accelerated and decelerated. The value can be specified in 1 of 3 forms. R (Ramp) is used if the required acceleration/deceleration is specified in steps. RT (Ramp Time) is used if the required acceleration/deceleration is specified in terms of time, and RS (Ramp Slope) is used if the required acceleration/deceleration is specified in steps/second². Ramp Slope can be used advantageously if the Top Rate or Start Rate are repeatedly changed in a program, since the acceleration per unit of time remains the same. If too high an acceleration/deceleration rate is selected, the motor will stop.


R [n] can be specified in the range 1 to 10000 steps. The default Ramp is 100 steps.

RT [n] can be specified in the range 1 to 1000, corresponding to a range from 0.01 to 10 seconds.

RS [n] can be specified in the range 10 to 30000 steps/second².

Examples:

R100 specifies an acceleration/deceleration of 100 steps. RT50 results in an acceleration/deceleration time of 0.5 seconds. RS900 gives an acceleration/deceleration rate of 900 steps/second².



All 3 parameters must be specified in a program and can be adjusted at any point in the program. If T (Top Rate) is set to a value less than S (Start Rate), the motor will operate at the Top Rate specified by T without accelerating or decelerating.

4.4

Motor Commands

r [n1.n2] These 3 commands are used to determine the motor parameters R, S (A/D Ramp Step) and T using the analogue voltage applied at one of the 6 Analogue Inputs.

s [n1.n2] The r [n1.n2] command determines the Ramp Step parameter.

(A/D Start Rate) The s [n1.n2] command determines the Start Rate parameter

The t [n1.n2] command determines the Top Rate parameter.

t [n1.n2]

(A/D Top Rate)

n1 specifies the Analogue Input used for controlling a given step/frequency. n1 can be specified in the range 1-6 corresponding to the required Analogue Input 1 to 6. The voltage applied to the specified input must be in the range 0 to 5.10V.

n1	Analog Input
1	AN1
2	AN2
3	AN3
4	AN4
5	AN5
6	AN6

n2 specifies the value corresponding to full-scale input voltage (5.10V) either in terms of steps for the r [n1.n2] command, or in terms of frequency for the s [n1.n2] or t [n1.n2] command.

n2 can be specified as a value in the range 1 to 10 according to the following table for Ramp, Start Rate and Top Rate.

n2	r[n1,n2] step	s[n1,n2] step/sec	t[n1,n2] step/sec
1	100	100	1000
2	200	200	2000
3	300	300	3000
4	400	400	4000
5	500	500	5000
6	600	600	6000
7	700	700	7000
8	800	800	8000
9	900	900	9000
10	1000	1000	10000

A voltage of 0V at a specified Analogue Input always corresponds to either 16 steps for the r [n1.n2] command, or 16 steps/second for the s [n1.n2] or t [n1.n2] commands.

The VR, VS and VT commands can be used to verify current parameter settings. See the description of these commands for further details.

(continued on following page)

4.4

Motor Commands

(continued)

Example:

r [n1.n2]
(A/D Ramp Step) The command t1.4 is used in a program. When the program is executed, the Controller measures a voltage of 2.5V at Analog Input 1 (AN1). This voltage is converted to a frequency of:

s [n1.n2]
(A/D Start Rate)

$$\frac{2.5 \times 4000}{5.10} = 1960 \text{ Hz} = 1960 \text{ steps/second}$$

t [n1.n2]
(A/D Top Rate) This frequency is then used for the next motor movement. The specified value of n2 in the example results in 0V corresponding to a frequency of 16Hz and full-scale 5.10V corresponding to 4000Hz.

VR
(Verify Ramp) The Verify Ramp, Verify Start Rate, and Verify Top Rate commands can be used to verify the current values of the motor parameters R, S and T. VR returns the value of the Ramp Step "R" in steps. VS returns the value of the

VS
(Verify Start Rate) Start Rate "S" in steps/second. VT returns the value of the Top Rate in steps/second.

VT
(Verify Top Rate) *Example:* A verification of the current Top Rate is required. The following command string is therefore sent to the Controller:

VT (carriage return)

The Controller responds:

T1000 (carriage return)

Indicating the current Top Rate is 1000 steps/second.

VR, VS and VT can also be used to check the value of the motor parameters determined by the *r [n1.n2]*, *s [n1.n2]* and *t [n1.n2]* commands.

4.5

User Interface Commands

V2 (Verify I/O)

The Verify I/O command enables the status of User Inputs and Outputs to be determined. When the V2 command is sent to the Controller, it responds with a V followed by two parameter values between 0 and 7.

The first parameter indicates the voltage levels at the User Inputs. The second parameter indicates the voltage levels at the User Outputs.

The status of the Inputs and Outputs is determined from the returned parameters according to the following table:

			V				
Input			├───┘	Output			
3	2	1	├───┘	3	2	1	
0	0	0	=0	0=	0	0	0
0	0	1	=1	1=	0	0	1
0	1	0	=2	2=	0	1	0
0	1	1	=3	3=	0	1	1
1	0	0	=4	4=	1	0	0
1	0	1	=5	5=	1	0	1
1	1	0	=6	6=	1	1	0
1	1	1	=7	7=	1	1	1
0=Logic"0"			1=Logic"1"				

Example:

The Verify I/O query returns a response V25, which indicates that Input 2 is logic "1", and Outputs 1 and 3 are logic "1".

The Verify I/O command is used exclusively when there is a constant interface connection between a computer/terminal and the Controller. It cannot be used in a program.


VA [1-6] (Verify ainput)

The Verify AInput command is used to determine the voltage at a specified AnalogueInput. 8-bit resolution is used for the measurement, which results in the measured value being given in 20mV steps with 5.10V as the maximum value. The Verify AInput command can be used when the Controller is in Standby Mode. The 3 User Inputs can, for example, be connected to 3 Analogue Inputs and thus verify that the voltages are as expected.

4.5

User Interface Commands

VA (Verify ainput) The Verify AInput returns the digital levels at the Analogue Inputs. The response string has the following format:



Example:

The command string "VA" is sent to the Controller.
The following response is returned:

VA101001 (Carriage return)

indicating that Analogue Inputs 1, 3, and 6 are logic 1 (>2.5V), and Analogue Inputs 2, 4, and 5 are logic "0" (<2.5V).

W [1-3] The Wait For command stops program execution until logic "1" is applied to a specified input. If the command character is followed by a number from 1 to 3, the specified input is one of the 3 User Inputs. If the command parameter is A1 to A6, the specified input is one of the 6 Analogue Inputs.

W [A1-A6]
(Wait For)

Example:

.
.
A3
G+372
W1 - Pauses program execution until User Input 1 is logic "1".
G+46
C1
D20
WA5 - Pauses program execution until Analogue Input 5 is logic "1".
.
.

4.6

Flow Control Commands

D [1-32000] The Delay command pauses program execution. The command character must be
(Delay) followed by a parameter value between 1 and 32000 which specifies the Delay duration in
 1/100 second.

Example:

D27 - results in a delay of 0.27 seconds.

DA[n].[n1-n2] The Analog Delay command is used to set a delay in program execution which is
(Analog delay) determined by one of the Analogue Inputs and can vary from 0.01 to 320 seconds.

Command Format:

n: Specifies which Analogue Input is used to control the delay.

n1-n2: Specify the required delay duration. n1 is the lower limit and corresponds to the
 delay when a voltage of 0V is applied to the specified input. n2 is the upper limit
 and corresponds to the delay when a voltage of 5.10V is applied.

Example:

DA2.10-100 - Enables a delay of between 0.1 and 1.0 seconds, controlled by a voltage
 of between 0 and 5.10V applied to Analogue Input 2.

J [n1] The Jump command is used to make an unconditional jump to a specified line
(Jump) number in the program.
 The program line number "n1" can be specified in the range 0-255.

Example:

Line no.:

0	A1
1	+1000
2	A2
3	G+5
4	C2
5	J2

The Jump command at line 5 in the above example causes the A2 , G+5 , and C2
commands (lines 2 to 4) to be continuously repeated. The program can only be interrupted
using the Z (Smooth Stop) or K (Kill) command.

4.6

Flow Control Commands

JC [0-7].[0-255] In contrast to the *J* (Jump) command, the *JC* (Jump Conditional) command is used (Jump Cond.) to make a conditional jump to a specified line number in a program, depending on the levels at all 3 User Inputs. The line number can be specified in the range 0-255. The condition for the jump to occur is specified according to the following table:

Example:

The command *JC5.10* results in a jump to program line 10 if User Inputs 1 and 3 are logic "1".

			JC_ . [nnn]
Input			
3 2 1			
0	0	0	=0
0	0	1	=1
0	1	0	=2
0	1	1	=3
1	0	0	=4
1	0	1	=5
1	1	0	=6
1	1	1	=7
0=Logic "0"			
1=Logic "1"			

Example:

Line no.:

0	S450	
1	R200	
2	A1	
3	+1200	
4	JC5.4	- Jumps to line 4 if User Inputs 1 and 3 are logic "1".
5	G+0	
6	C1	
7	JC3.2	- Jumps to line 2 if User Inputs 1 and 2 are logic "1".

4.6

Flow Control Commands

JC [p].[n1]
(Jump con.)

This conditional jump command is similar to JC[0-7] - if an input level condition is fulfilled, a jump is made to a specified program line. In contrast to the JC[0-7] command however, the JC[p] jump condition is determined by the level at a specific Input and not by the pattern at all 3 User Inputs.

The JC[p] command can be used both with User Input levels and with the Analogue Inputs.

Command Format:

JC [i]=[n].[n1]

- i:** Specifies the input used for the jump condition.
A value of "i" between 1 and 3 specifies the corresponding User Input 1 to 3. A value of "i" between A1 and A6 specifies the corresponding Analogue Input 1 to 6.
- n:** Specifies the Reference Level to be compared with the measured level at the specified input. n can assigned a value of 0 or 1. If the level at the specified input is equal to the Reference Level, the jump is made.

n1: Specifies the program line to jump to if the jump condition is fulfilled.

Program Example:

Line no.:

0	S750	
1	R700	
2	C3	
3	+500	
4	JC2=0.3	- Jumps to line 3 if User Input 2 is logic "0".
5	G+0	
6	T1000	
7	A2	
8	JCA4=1.5	- Jumps to line 5 if Analogue Input 4 is logic "1".

When the Analogue Inputs are used as logic inputs, logic "1" corresponds to voltages greater than or equal to 2.5V, and logic "0" corresponds to voltages less than 2.5V.

4.6

Flow Control Commands

JCA [p].[n1]
(Jump Cond.)

This conditional jump command is similar to the JC command - if the level at a specified input fulfils the jump condition, a jump is made to the specified program line. In contrast to the JC command however, the JCA jump condition is determined by an analogue voltage level at one of the Analogue Inputs 1 to 6, and not by a logic level.

Command Format:

JCA [a1mn].[n2]

a1: Specifies the Analogue Input used for evaluating the jump condition.

mn: Specifies the Reference Level (n) with which the measured input voltage is compared and the operator for the comparison (m).

If "m" is specified as ">", the jump is made if the measured input voltage is greater than or equal to the Reference Value. If m is specified as "<", the jump is made if the measured voltage is less than the Reference Value.

The Reference Level "n" can be specified in the range 0 to 255.

n1: Specifies the program line number to jump to if the jump condition is fulfilled.

Since *n* is specified as a value in the range 0-255 and the measured voltage is a value in the range 0 to 5.10V, a conversion of voltage to a valid Reference Level value must be made when specifying the jump condition. The conversion is made as follows:

$$V_{ref} = 0.02 \times n \quad \text{or} \quad n = 50 \times V_{ref}$$

Example:

A Reference Value of 3.00V is required.

$$n = 50 \times 3.00 = 150$$

Program Example:

Line no.:

0 S450

1 R600

2 D2

3 +342

4 **JCA3>150.2** - Jumps to program line 2 if the voltage at Analogue Input 3 is greater than or equal to 3.00V.

5 G+0

4.6

Flow Control Commands

JS [n1]
(Jump Sub.)

In contrast to the *J* (Jump) command which jumps to a specified program line number, the *JS* (Jump Sub) command makes an unconditional jump to a program sub-routine.

When a *JS* command is executed, the Controller first stores the number of the next line after the *JS* command and then jumps to the line number specified by the *JS* command. When the *RET* (Return) command is encountered in the sub-routine, the program returns to the main program at the line immediately after the *JS* command and continues execution from there.

The *JS* command be used up to 32 times in a program, corresponding to 32 nested sub-routines.

L [0-255]
(Loop)

The Loop command is used to repeat execution of a specified program segment. The command parameter specifies the number of times the Loop is executed and can be specified in the range 1 to 255. The segment to be repeated must be delimited by a pair of Loop commands such as *L0* and *L5*, as illustrated in the following example.

Example:

```
      L0
      .
      .
      .
      (Program)
      .
      .
      .
      L5
      .
```

The program segment between *L0* and *L5* will be repeated 5 times. If the initial Loop delimiter *L0* is omitted, the entire program will be repeated from line 1.

4.7

Extended Command Set

SMC30 is equipped with 510 User Storage Registers which can be used for storing intermediate results, etc. These are designated R1 - R510. In addition, the Controllers are equipped with 7 predefined registers which can only be used for specific purposes. Register T for example is used to determine the motor Top Rate. The user- and predefined registers enable parameters such as lengths, speeds, acceleration, delay times, program loops, etc., to be continuously changed and controlled during program execution.

In addition, the User Register contents can also be stored permanently in the Controller's EEPROM memory. For example, parameters which have been set via Keyboard/Display Module KDM10 can thus be stored permanently in the Controller and recalled when the system is started up.

The following registers are available :

- R :** Predefined register for the number of steps used to accelerate/decelerate the motor (Ramp). Note that this register is completely independent of, and should not be confused with, User Registers R1 to R510.
- S :** Predefined register for Start Rate.
- T :** Predefined register for Top Rate.
- D :** Predefined register for program Delay.
- L :** Predefined register for program Loop Counter.
- n :** Predefined register for Position Counter in steps.
- A1-A6 :** Predefined registers for Analogue Inputs' level from 0-255 corresponding to voltages from 0-5.10V.
- R1-R510 :** 510 User Registers for intermediate results, etc.

Example 1:

```
R2 = 3000           ; Sets the value of register R2 to 3000
T = R2 + 100       ; Sets the Top Rate to 3100 steps/second for the next motor
                   ; operation.
```

Example 2:

```
R34 = 400
D = R34 + A1       ; Waits (400 + A/D conversion of Analogue Input 1 level) x 10ms
```

Example 3:

```
R1 = n + R2       ; Sets the value of R1 to value of the Position Counter in steps + R2
```

Example 4:

```
R1 = 350 + 700    ; Sets the value of R1 to 1050
+(R1)             ; Advance the motor 1050 steps.
```

Example 5:

```
R30 = 100         ; Sets the value of R30 to 100
R31 = 200         ; Sets the value of R31 to 200
R34 = R30 + R31   ; Sets the value of R34 to value of R30+R31
G+(R34)          ; Goto (move motor to) position R34
```

4.7

Extended Command Set

Register description.

In addition, register arrays can be defined by using one register to point to the contents of other registers. This enables, for example, the contents of a block of registers to be copied to a different array.

Example 6: The contents of ARRAY1 (registers 100-199) are copied to ARRAY2 (registers 300-399)

```
R1=100      ; Set Array 1 pointer
R2=300      ; Set Array 2 pointer
L0          ; Loop delimiter for copying 100 registers
R(R2)=R(R1) ; Copy contents of a register in array1 to register in array2
R1=R1+1     ; Increment the Array 1 pointer to the next register
R2=R2+1     ; Increment the Array 2 pointer to the next register
L99        ; Repeat Loop until the contents of all 100 registers have been copied.
```

Rules for Register Operations:

- 1: An "is equal to" sign "=" is used to assign the contents of a register. A maximum of 3 registers may be used in an assignment expression:

e.g. $R3=R23+T$ is legal, but $R3=R23+T-100$ is illegal.

- 2: The following 4 arithmetic operators can be used in register operations:

+ : Addition
- : Subtraction
* : Multiplication
/ : Division

- 3: All values and register contents must be integers in the range 0 to 65535. For division however, all operands must be max. 32767 or an error will result.

- 4: The result of division is always rounded down.

Example:

$R2=289/10$; Calculates the result of 289 divided by 10.

$PRINT(5.R2)$; The result is rounded down, the printed result is 28.

- 5: The R, S, T, L and D registers can be assigned values using an "equals" sign, but a quicker method, both in terms of programming and at run-time, is to assign values directly to these registers. If the required value is known and a constant, it can be directly assigned to the register.

Example:

T2000 is equivalent to $T=2000$

D200 is equivalent to $D=200$

S500 is equivalent to $S=500$

- 6: When "if" expressions are used for numeric comparison, the values to be compared must be maximum 32767. This is valid both for register contents and numeric values.

4.7

Extended Command Set

VR[0-510] (Verify)

The Verify Register command is used to verify the contents of a register.

Example:

VR9 ; Returns the contents of register R9.

I[5-7] (Initialize)

The Initialize command is used to save or recall the contents of all 510 User Registers to or from the Controller's permanent EEPROM memory. The command is also used to reset (erase) all 510 register contents.

The Initialize command can be used both in Standby Mode and Programming Mode.

Example:

I5 ; Resets (erases the contents) of all 510 User Registers.

I6 ; Stores the contents of all 510 registers in EEPROM.
; The predefined registers (R,S,T etc.) are not stored in EEPROM

I7 ; Recalls the contents of all 510 User Registers from EEPROM.

con=n

The Conversion command is used to set a conversion factor between the number of steps a motor moves and a unit of measurement such as length, volume, position, etc. "n" specifies the number of steps per unit length, volume (mm, ml, cm, dl, etc). The conversion factor can be specified as a real number in the range 0.0001 to 1600.0000, with up to 4 decimal points.

The conversion factor command is inserted at the beginning of a program and stays in effect until any subsequent conversion factor is specified at run-time. When a motor operation is performed, the number of units specified by the motor command is multiplied by the conversion factor and the motor moves the resulting number of steps.

If, for example, a motor must move 2.3456 steps to dose a volume of 1 millilitre, the conversion factor is set to a value of 2.3456 using the command *con=2.3456*. To dose a volume of 450 ml in a subsequent motor command, the value 450 is specified. The conversion results in $450 * 2.3456$ (1055.52) steps. The motor will then move 1055 steps and the remainder (0.52 steps) will be stored. The remainder is used in the next motor operation to correct for the 0.52 dosage steps.

Example:

A system requires motor operation of 14.654 steps to dose a volume of 1 ml.

```

con=14.654      ; The conversion factor is set to 14.654 steps per millilitre.
R1=290         ; A value of 290 is assigned to register R1.
+(R1)         ; The motor is moved to provide a dose of 290 ml.
              ; The number of steps run is  $290 * 14.654=4249$ . The step
              ; remainder is 0.66
D100          ; Delay of 1 second.
+18           ; Dose 18 ml. The number of steps is
              ;  $18*14.654+step\_remainder=264$ .
              ; The new step remainder is 0.432

```

Note that after a "Home" operation using the H command, the step remainder is reset to 0 since the motor is set to its absolute reference point.

PRINTn1.n2.n3 The Print command is used to print out the contents of registers to external modules. At present, print-out to 4 external modules is possible: to a PC via the RS232 interface and to DIS10, KDM10 and IOM10 Modules via the RS485 interface.

Command Format :

n1 : Specifies the address of the module to be printed to (1-31). Address 255 is reserved for a PC.

n2 : Specifies the register or cursor position to be printed to in the external module.

n3 : Specifies the register, numeric value or text string in the Controller to be printed.

Example 1:

PRINT1.0.R23

Prints the contents of register R23 to the module whose interface address is 1. Since transmission via the RS485 interface is balanced, it is possible to locate external modules up to 500 metres from the Controller.

Example 2:

PRINT255.0.R2

Prints the contents of register R2 to a PC via the RS232 interface. Address 255 is reserved as the address for PCs. Note that the Print command can be used to print out register contents at run-time. It is especially well-suited for debugging a program. If JVL's "Editor2" program is used, once the Controller program has been transferred using the F5 function key, the F6 function key can be used to switch to the communication window where register contents will be displayed when a Print command is executed at run-time.

Example 3:

PRINT3.41."Key in Value: "

When a Keyboard-Display Module KDM10 is incorporated in a system, it is often desirable to display information to the user. The above example illustrates how text can be written to the module's LCD display. In the example, the address of the module is 3. The second parameter value is cursor position 41, which is the first character on line 2 of the display.

Example 4:

```
R1=5555      ; Assign a value of 5555 to register R1
R30=333      ; Assign a value of 333 to register R30
PRINT5.41.R1 ; Print the contents of register R1 to cursor position 41 of a KDM10
              ; module with address 5
PRINT2.0.R30 ; Print the contents of register R30 to the display of a DIS10 module
              ; with address 2.
```

When external modules DIS10 or KDM10 are used in a system, it is often necessary to print out the contents of register on the displays of the modules. As illustrated in the above example, this is best accomplished using the PRINT command to print the contents of a register either to a cursor position or directly to the LED display of the DIS10 module.

4.7

Extended Command Set

IF [p1 m p2]

The IF command is used for comparison of 2 numeric values, p1 and p2. These values may be the contents of registers such as R1, A1, T etc., or simply integer values such as 10500, 420, etc. All registers described in the "Register Description" section at the beginning of this Chapter can be used in IF expressions. The comparison operator "m" may be one of the following :

m	Condition fulfilled if:
<	Less than
>	Greater than
=	Equal to
<=	Less than or equal to
>=	Greater than or equal to
<>	Not equal to

If the condition specified by the IF expression is fulfilled, the next line of the program is executed. If the condition is not fulfilled, the next line is omitted and execution continues from there.

Example 1:

```
:START IF R10 < 9800 ; If the content of register R10 is less than
      J:PROG1 ; 9800, jump to label PROG1.
      J:PROG2 ; else jump to label PROG2.
```

Example 2:

```
T=100 ; Set Top Rate to 100 steps/second
:START T=T+50 ; Increase Top Rate by 50
      IF T>4000 ; If the Top Rate is greater than 4000 steps/s
      J:SPEEDOK ; Jump to label SPEEDOK
      +1000 ; else move 1000 steps clockwise
      J:START ; Jump to label START, where the speed is increased
```

The above program moves the motor 1000 steps at a speed of 150 steps/second and increases the Top Rate by 50 steps/second until a Top Rate of 4000 steps/second is reached.

INPUTn1.n2.n3 The INPUT command is used to read-in data from external modules connected to the RS485 interface. It can be used to read-in data from modules such a Keyboard, Display, thumbwheel, BCD data from PLC equipment, printer, extra inputs, digital-to-analogue modules, etc.

All of the above-mentioned external modules are intelligent and will therefore contain registers whose contents can be read into the Controller's registers using the INPUT command. The size and number of registers in external modules may vary, but each module has at least 1 register.

Command Format :

n1: Specifies the address of the external module from which input is required. The address parameter must be specified as a value between 0 and 31. The RS485 interface enables up to 32 modules to be connected to the interface. The address of each module must be set via DIP switches on the individual module.

n2: Specifies the register in the external module from which input is to be read. n2 must be specified in the range 0-255.

n3: Range-check. Specifies the allowable range of the register contents. If the register content is outside the specified range, program execution is terminated. n3 must only be specified if the external module supports range-checking.

Example 1:

An IOM10 module has 16 inputs and 8 outputs are used. The Module address is 5. All 16 inputs are to be read and tested to determine if the value is 255. If this is the case, the module Counter is read and the program continues.

In the instruction manual for the IOM10 module, the Counter register is specified as register 2 and the register for all 16 inputs is 3.

```
:READINP          R10=INPUT5.2      ; Read all 16 inputs and transfer contents
                                     ; to R10.
                                     IF R10=255      ; If inputs not equal to 255 read again
J:READ_COUNTER
                                     J:READINP        ; else read Counter value and continue
                                     ; program

:READ_COUNTER     R30=INPUT5.3      ; Read Counter and transfer to R30
                                     R(R1)=R30        ; Transfer Counter value to an array
                                     ; register using R1 as array pointer.
```

AO[a].[o] The Activate command is used to activate a flag in an external module whose address
(Activate) is specified by "a".

The Flag number is specified by "o". For example, the flag may refer to an output on a IOM10 module. When the flag is activated, an output will be activated. A flag in a different module may refer to a completely different function. For example if flag 3 in a KDM10 module is activated, the cursor on the module's LCD display will blink. Flags with the same number in different modules can have different functions. See the instruction manual for the individual module for a description of the function of the module's flags.

Format: **AO{1<=a<=31}.{1<=o<=255}**

Example 1:

A Keyboard-Display Module has address 4. The module display is to be erased so that new text can be displayed. The following command will erase the display and position the cursor at the top left-hand corner of the display.

AO4.1 ; Erase LCD display

Example 2:

An IOM10 module and SMC30 are connected together in a system. The IOM10 module address is 10. Output 4 is to be activated. The following command is used:

AO10.4

CO[a].[o] (Clear) The Clear command is used to clear a flag in an external module. The number of flags which that can be cleared in different external modules varies, but each module has at least 1 flag. For the KDM10 module (Keyboard-Display Module) for example, the Clear command can be used to clear the LCD display; in the IOM10 module (I/O module) the Clear command can be used to deactivate one of the module's outputs, etc.

Format: CO {1<=a<=31},{1<=o<=255}

Example 1:

Controller Type SMC30 and a KDM10 module are connected in a system via the RS485 interface. The address of the SMC13 is 1 and the KDM10 module address is 3. The Cursor on the KDM10's LCD display is to be switched off. If the cursor is active while text is being printed using the PRINT command, the display may flicker. This is avoided by switching off the cursor as follows:

CO3.3 ; Deactivate cursor

Example 2:

Controller Type SMC30 and an IOM10 module are connected in a system via the RS485 interface. The IOM10 module's address is 5. The IOM10's output 7 is to be deactivated. The command is as follows:

CO5.7 ; Deactivate output 7 on IOM10 module with address 5.

5.1

Electrical Specifications

	Min.	Typical	Max.	Units
Power Supply :				
Supply Voltage (230V Pos.)	207	230	245	VAC
Supply Voltage (110V Pos.)	85	110	130	VAC
Power Consumption (unloaded, no motor)		7		W
User Supply :				
Output Voltage (adjustable)	5.1		30.2	VDC
Rated Current			500	mADC
Motor Driver :				
Output Current (per phase)	0,0		6/(12)	ADC
Output Voltage (no motor)		150		VDC
Chopper Frequency		22		kHz
Interface :				
on	-1		-12V	
Rx space position	2.5		12	V
Tx mark position	-3		-12	V
Tx space position	5		12	V
Communication Rate	110		9600	Baud
Isolation Voltage*			500	V (Max.)
Module Interface :				
Communication Distance	0		500	m
Communication Rate	50		kbit/sec	
Isolation Voltage			* 1000	V (Max)
User Inputs 1-3 & Stop Input :				
Input Impedance	10			kohm
Supply : Voltage	5		32	V DC
Current at 5V	-		10	mA DC
at 12V	-		20	-
at 30V	-		45	-
Logic "0" at 5V	<1.7		-	VDC
at 12V	<3.0		-	-
at 30V	<6.7		-	-
Logic "1" at 5V	-		>2.7	-
at 12V	-		>6.5	-
at 30V	-		>16.2	-

* Measured from Supply ground to Interface ground

() Values valid for Type SMCxxC.

(Continued on following page)

5.1


Electrical Specifications

	Min.	Typical	Max.	Units
Analog Inputs :				
Resolution	-		8	Bit
Input Voltage (Max allowable)	-20		** 45	V DC
Input Voltage (Nominal)	0.00		5.10	V DC
Offset Error	-	$\pm\frac{1}{2}$	± 1	LSB
Gain Error	-	$\pm\frac{1}{2}$	± 1	LSB
Temperature Drift @ 0-50°C	-	$\pm\frac{1}{4}$	$\pm\frac{1}{2}$	LSB
Logic "0"	<2.5		-	V DC
Logic "1"	-		>2.5	-
CW/CCW Inputs :				
Input Impedance	2.4		3.3	kOhm
Logic "0" (inactive) (-30)		3.0	V DC	
Logic "1" (active)	3.8		30	V DC
User Outputs :				
Supply Voltage	5		30	V DC
Rated Output Current per output				
1 output activated @25°C		700	mA DC	
2 outputs activated @25°C		460	mA DC	
3 outputs activated @25°C		300	mA DC	
Operating Temperature Range :	0		50	°C

** Absolute max. time < 1 sec.

5.2

Physical Dimensions



If the Controller is mounted in a closed cabinet, a ventilation fan or other form of cooling should be installed. The Controller is however protected against overheating by a built-in thermo-switch which disconnects the driver stages at a temperature of approximately 80 °C.

5.3

Memory Utilization

The permanent memory of the Controller consists of a 8kbyte E²PROM.

4 bytes are used to correct the A/D converter offset-error and for adjustment of the Controller's thermometer function (TP).

In order to enable optimum utilization of the 8kbyte available memory, the following table gives the memory requirements of each program command. The total size of a program must not exceed 8186 bytes.

If an attempt to store a program greater than 8186 bytes is made, the Controller will issue an error message "E3".


1 byte :	g± H± RET (Blank line)	5 bytes : con=[nnnn.nnnn]
2 bytes : A[n]	C[n] I[n] r,s,t[n.n] U[n] W[n] L[nnn] J[nnn] JS[nnn]	6 bytes : DA[n].[n1-n2] ±A[n].[n1-n2] G±A[n].[n1-n2]
3 bytes : AO[n.n]	CO[n.n] CR[nnnn] CS[nnnn] CT[nnnn] R[nnnnn] RS[nnnn] RT[nnnnn] S[nnnn] T[nnnn] N[nn.nn] D [nnnnn]	7 bytes : NA[p1-p2]
4 bytes : f [±nnnnnnn]	± [nnnnnnn] G [±nnnnnnn] JC[n.nnn] JCA[p].[n1]	10 bytes : PRINT(typ.)
		12 bytes : R[n]=x INPUT[n.n.n]
		14 bytes : R[n]=x+x
		17 bytes : IF(max.)

5.4 Application Example for Controller Type SMC30

The following example illustrates how 2 Controllers can be used for motion control of an X-Y Table. The Table is used to drill 2 holes in an aluminium block. Two stepper motors are mounted. In addition, an inductive sensor is used for each axis to register when the respective axis has reached its mechanical reference position (0 position). The feeler gauge distance should be as small as possible (typically 1-2mm) since it greatly determines the repetition accuracy.

This is important because the inductive sensors determine the reference points for the X and Y axes and thus the accuracy of the entire system. A sensor with a gauge distance of 1mm will typically result in a repetition accuracy of $\pm 1/100$ mm, which should be sufficient for the majority of applications. The drill itself is not described here, but could for example consist of a DC motor vertically driven by a hydraulic/pneumatic cylinder.

Plan View of X-Y Table:



5.4 Application Example for Controller Type SMC30

Electrical Connections.

Before the actual task of programming the Controllers is started, it is recommended that the input and output signals of the system are clearly defined.

A Start button is connected to the Y-axis controller to start the system.

The following elements must be handled by the system:

- 1) 2 Stepper motors.
- 2) 2 Inductive Sensors with NPN outputs (0V at the output when activated).
- 3) A drill which is activated by a voltage pulse of 0.1 second duration. The drill outputs 12V when the holes have been drilled and the drill unit has returned to its start position.
- 4) A Start button.
- 5) Internal synchronisation signals between the 2 Controllers. (See program description.)

The following page illustrates the electrical connection of the system.

The Controllers' User Outputs and Inputs are used in the following manner:

X-Controller.

Input 1

Used to receive "ready" signal from the Y-controller.

Input 2

Used to receive "ready" signal from the drill.

Input 3

Inductive Sensor (X-axis)

Output 1

Used to send "ready" signal to the Y-controller.

Output 2

Used to send start impulse to the drill.

Output 3

Not used.

Y-Controller.

Input 1

Used to receive "ready" signal from the X-controller.

Input 2

Used for the Start button.

Input 3

Inductive Sensor (Y-axis).

Output 1

Used to send "ready" signal to the X-controller.

Output 2


Not used.

Output 3

Not used.

5.4 Application Example for Controller Type SMC30

See Chapter 2 for the locations of individual connectors.



5.4 Application Example for Controller Type SMC30

Program for Control of the Drilling Application.

Before programming is started, the values of all parameters should be defined.

Holes are to be drilled in the aluminium block at the following coordinates:

Hole 1 - 4013,7387

Hole 2 - 5164,1949

The coordinates are specified in steps relative to the reference point of the inductive sensors.

The drill unit is activated by a voltage impulse of 0.1s duration. Once the holes have been drilled, the drill unit moves to its start position and outputs a constant voltage of 12V to indicate that the drilling operation is complete.

The sequence of instructions to be programmed for the application can be described as follows:

1. If the start button is activated, continue to point 2.
2. Go to position 4013,7387
3. Drill hole
4. Go to position 5164,1949
5. Drill hole
6. End, Go to point 1

If this procedure is followed, the system will wait until the start button is activated, drill 2 holes and wait until the start button is activated again.

Before the instructions for an application are programmed, it is recommended that a flow chart is made to give a better overview of the programming task. The remaining work is then largely determining and using the appropriate commands.

A flow chart for the drilling application is given on the following page.

5.4 Application Example for Controller Type SMC30

Program Flow Chart for Control of X-Y Table.

X-Controller.

Start:

- 1) Continue when "ready" signal is received from Y-controller.
- 2) -
- 3) Move to position 4013.

- 4) Continue when "ready" signal is received from Y-controller.
- 5) Send a start signal to the drill unit.
- 6) Continue when the drill unit is finished.
- 7) Send "ready" signal to the Y-controller.
- 8) Move to position 5164.

- 9) Send a start signal to the drill unit.
- 10) Continue when the drill unit is finished.
- 11) Send "ready" signal to the Y-controller.
- 12) Go to point 1.

Y-Controller.

Start:

- 1) If the Start button is activated, continue to point 2.
- 2) Send "ready" signal to the X-controller.
- 3) Move to position 7387.

- 4) Send "ready" signal to the X-controller.
- 5) Continue when "ready" signal is received from the X-controller.
- 6) -
- 7) -
- 8) Move to position 1949.

- 9) Continue when "ready" signal is received from the X-controller.
- 10) -
- 11) -
- 12) Go to point 1

Note:

A dash in the above indicates that the respective Controller is waiting for the other Controller to complete an operation and send a "ready" signal.

5.4 Application Example for Controller Type SMC30

Program for Control of X-Y Table.

The basis for the actual program has thus been laid in the above overview and flow chart. The actual Controller instructions can then be programmed as shown below. Note that the numbers to the left of the columns below refer to the respective step in the above flowchart. Note that not all steps in the flowchart can be directly translated to a single program command.

For example, each time the X-controller sends a "ready" signal to the Y-controller, or vice-versa, 3 program commands are required.

Each time a ready signal is transmitted between the two Controllers, this is accomplished by sending a voltage impulse. The impulse duration is set to 1 second, since the receiver must be able to register the signal. The impulse is sent by the sender activating its output. A delay of 1 second is then made, after which the sender deactivates its output. This operation involves the use of 3 program commands: *A1 - D10 - C1*.


X-Controller.

- 1) H- (Reset)
- 2) W1 (Wait for Input 1)
-
-
-
- 4) G+4013 (Move to position +4013)
- 5) A1 (Activate Output 1)
-
-
- 6) A2 (Activate Output 2)
- D1 (Wait 0.1 seconds)
- C2 (Deactivate Output 2)
- 7) W2 (Wait for Input 2)
- 8) A1 (Activate Output 1)
- D10 (Wait 1 second)
- C1 (Deactivate Output 1)
- 9) G+5164 (Move to position +5164)
- 10)A2 (Activate Output 2)
- D1 (Wait 0.1 seconds)
- C2 (Deactivate Output 2)
- 11)W2 (Wait for Input 2)
- 12)A1 (Activate Output 1)
- D10 (Wait 1 second)
- C1 (Deactivate Output 1)
- 13)J1 (Jump to point 2)


Y-Controller.

- 1) H- (Reset)
- 2) W2 (Wait for Input 2)
- 3) A1 (Activate Output 1)
- D10 (Wait 1 second)
- C1 (Deactivate Output 1)
- 4) G+7387 (Move to position +7387)
- 5) A1 (Activate Output 1)
- D10 (Wait 1 second)
- C1 (Deactivate Output 1)
- 6) W1 (Wait for Input 1)
-
-
-
- 9) G+1949 (Move to position +1949)
- 10)W1 (Wait for Input 1)
-
-
-
-
- 13)J1 (Jump to point 2)


**Connection of MAE motor
Type HY200-xxxx-xxx-x8**




**Connection of MAE motor
Type HY200-xxxx-xxx-x4**




**Connection of Phytron motor
Type ZSx . xxx.x,x**




**Connection of Zebotronics motor
Type: SMxx.x.xx.x**



**Connection of Wexta motor
Type: PH2xx-xxx**



**Connection of Teco motor
Type: 4Hxxxx**



- +/-, 37
- ±A, 37
- A, 47
- acceleration, 44
- Activate output, 47
- Addressing, 22
- Analogindgange**, 16
- AO**, 64
- Brugerindgange, 14
- Brugerudgange**, 12
- byte, 69
- C**, 47
- Checksum, 25
- Clear output, 47
- CO**, 65
- Command Overview, 31; 32; 33
- Command Syntax, 24
- Communication Rate, 23
- con**, 59
- Controller Response, 30
- conversion, 59
- D**, 50
- DA**, 50
- deceleration, 44
- Delay, 50
- E**, 34
- Electrical Specifications, 66; 67
- Endestopindgange, 17; 18
- Error, 30
- Execute, 34
- F**, 34
- f+/-**, 34
- Feedback, 34
- Flow Control Commands, 50; 51; 52; 53; 54
- Forcing pos., 34
- g+/-**, 39
- Goto, 39
- H+/-**, 39
- Home, 39
- I**, 34
- IF**, 62
- Indgangshysterese**, 15
- Initialize, 34
- INPUT**, 63
- Input setup, 40; 42; 43
- Interface, 20
- J**, 50
- JC, 51
- JCA**, 53
- JS**, 54
- Jump, 50
- Jump con., 51
- K**, 34
- Kill, 34
- L**, 54
- Lagre, 28
- Loop, 54
- Memory, 35; 69
- Modes, 29
- Module Interface, 26
- Motor Commands, 37; 38; 39; 40; 41; 42; 43; 44
- Motorcommands, 45
- Motorkommandoer, 46
- N**, 40; 42; 43
- NA**, 43
- Pause, 50
- PE**, 35
- Physical Dimensions, 68
- PO**, 35
- Position Counter.**, 28
- PRINT**, 60
- Program, 35
- Program enter, 35
- R**, 44
- r-, 45
- Ramp step
 - A/D ramp step, 45
- Recall prog., 36
- Relative, 37
- Reply Code**, 30
- Return**, 24
- s-**, 45
- S**, 44
- Smooth stop, 36
- Speed, 44
- Start rate, 44
 - A/D start rate, 45
- Steppermotor, 44
- Stop, 34
- Stopindgang**, 19
- System Commands, 34; 35; 36
- T**, 44
- t-**, 45
- Temperature, 36
- Top rate, 44
 - A/D top rate, 45
- TP**, 36
- U**, 47
- Until, 47
- User Interface, 47; 48; 49
- User Output, 34
- V1**, 36
- V2**, 48
- VA**, 48; 49
- Velocity mode, 39
- Verify
 - Verify ainput, 48
 - Verify I/O, 48
 - Verify pos., 36
 - Verify ramp, 46
 - Verify start rate, 46
 - Verify top rate, 46
- Verify ainput, 49
- VR**, 46
- VS**, 46
- VT**, 46
- W**, 49
- X**, 36
- Z**, 36